


Series CS30 absolute 4...20mA heavy duty shaft encoder up to 12mm





(2 wire version has 82mm diameter housing)

Technical Data

Operating temp: - 20 ...+ 60 degrees C

- 4 ...+ 140 degrees F On request: -20 ... + 100 degrees C

Current consumption: 80 mA (max.)

Power supply: 24V

Weight: 42 oz (1.2 kg) Stainless Steel Housing: Shaft: Stainless Steel Bearings: 2 x 6001 ZZ 0.4 oz/in (3 N-cm) Torque: Humidity: Up to 98% permissible Speed: 3000 RPM max. Shaft load: Radial / Axial 10 N

Connection Options

2 wire version (intrinsically safe Ex ia IIC)

Zone 0, Class 1 Div 1

	4 pin plug	Cable
+ Loop	1	Red
- Loop	2	Black



3 wire version (standard)

	4 pin plug	Cable
PS GND	1	Black
PS +24V	2	Red
Output 420mA	3	White

Resolution

Intrinsically Safe version: (10 bits)

0360 = 1024 counts per current ramp

1 ramp per turn (360 degrees per ramp)

0180 = 512 counts per current ramp

2 ramps per turn (180 degrees per ramp)

0090 = 256 counts per current ramp

4 ramps per turn (90 degrees per ramp)

Non-intrinsically Safe version: (12 bits)

0360 = 4096 counts per current ramp

1 ramp per turn (360 degrees per ramp)

0180 = 2048 counts per current ramp


2 ramps per turn (180 degrees per ramp)

0090 = 1024 counts per current ramp

4 ramps per turn (90 degrees per ramp)

Output

Count will increment in CW direction.



*4...20mA span based on 250 ohm load



Certifications

Best suited to work with the following isolators: MTL5541

ATEX


IECEx

CSA


GOST (CU)

Mounting Instructions

To mount encoder on machine: Option 1 is to mount with three screws, option 2 is to use synchroflange mounting brackets. Hook up the encoder with the connections as described. Make sure power supply meets specifications. Attach encoder to mounting bracket as shown. Attach shaft using a flexible coupling.



Dimensions (3 wire version)



Dimensions (2 wire version)



Certifications

Best suited to work with the following isolators: MTL5541

ATEX


IECEx

CSA


GOST (CU)

Mounting Instructions

To mount encoder on machine: Option 1 is to mount with three screws, option 2 is to use synchroflange mounting brackets. Hook up the encoder with the connections as described. Make sure power supply meets specifications. Attach encoder to mounting bracket as shown. Attach shaft using a flexible coupling.



Dimensions (3 wire version)



Dimensions (2 wire version)